

## Air Brake Bleeder



### TECHNICAL DATA

Working pressure: 6-12 bar  
Sound power level (L<sub>w</sub>A): 77.3 dB(A)  
Sound pressure level (L<sub>p</sub>A): 88.5 dB(A)  
Vibration level (ahd): 0.029 m/s<sup>2</sup>  
Vibration level (K): 0.499 m/s<sup>2</sup>  
Recommended hose: 10 mm (3/8") inner diameter

### ATTENTION

Read the operating instructions and all safety instructions contained therein carefully before using the product. Use the product correctly, with care and only according to the intended purpose. Non-compliance of the safety instructions may lead to damage, personal injury and to termination of the warranty. Keep these instructions in a safe and dry location for future reference. Enclose the operating instructions when handing over the product to third parties.

### SAFETY INFORMATIONS

- Keep children and other persons out of the working area.
- Do not allow children to play with this tool or its packaging.
- Brake systems should be maintained by qualified personnel only!
- Secure your vehicle against unintended movement.
- Always follow the manufacturer's recommendations.
- Do not leave brake fluid out in the open. Brake fluid is hygroscopic which means it will absorb humidity out of the air. The existence of water in brake fluid will decrease its boiling point and may cause a total malfunction of your brake system.
- Always use new and unused brake fluid; used and worn out brake fluid may cause a total malfunction of your brake system.

### COMPONENTS

- 1 Air inlet
- 2 Holding clamp for trigger lever
- 3 Trigger lever
- 4 Air outlet (Muffler)
- 5 Container
- 6 Bleeding hose (Flexible)
- 7 Bleeding adapter
- 8 Suction hose (Rigid)
- 9 Hose connector (8 to 6)



