




Instruction & Maintenance Manual for SLIX 100 Stretcher



IMPORTANT PLEASE READ THIS MANUAL BEFORE USING THE SLIX100

This is not a manual of First Aid or Rescue techniques.

The SLIX stretcher may be used as a simple carry stretcher.

Rescuers using SLIX100 equipment involved in technical rescues from height or from confined spaces using SLIX equipment should be trained in these disciplines.

It is the responsibility of the rescue team to ensure that the casualty is secure at all times and that all ropes, karabiners, slings or any other equipment attached to, or used to lift the Slix Stretcher is of suitable strength and in good order.

All belays must be correctly installed and used by a competent person or persons.

Before using the Slix Stretcher check for wear or damage. Do not use if worn or damaged.

When lifting or lowering a Slix Stretcher in the vertical or horizontal mode a separate lifeline of suitable strength should be used and standard-belayed separately.

The rescue team must be able to deal safely with any emergency that may arise during the evacuation of a casualty.

The Slix100 Stretcher

The Slix Stretcher may be used to raise or lower a casualty vertically or horizontally.

When correctly applied the Slix is a safe, protective stretcher that may be used in the most adverse conditions.

The adjustable Closure and Foot loops will accommodate casualty insulation and applied first aid equipment such as leg splints and the Spinal Splint.

The configuration of the confined space will dictate how the Slix Stretcher can be raised or lowered. If circumstances allow, for medical considerations, the casualty should be raised or lowered in a horizontal position.

The Stretcher Strops are colour coded to allow the rescuers to choose to raise or lower the casualty in a Head Up or Level orientation, as dictated by any injuries.

By attaching the Green Stretcher Strop to the Green Horizontal attachment points and the Blue Stretcher Strop to the Blue Horizontal attachment points, a slight head Up attitude is achieved. By reversing the Stretcher Strops - a level attitude is achieved.

Stretcher Strops must only be connected to the stretcher using the colour coded attachment eyelets. No other part of the stretcher or closure straps should be used for load supporting. Colour coded attachment points are rated at 400kg WLL.

All closure straps must be correctly fastened and any surplus length securely tucked away to prevent snagging.

All equipment used for raising or lowering the Slix Stretcher must be of suitable strength and condition.

Haul ropes and Lifelines must be to a minimum of EN1891 Type A standard.

The recommended rope for hauling and lifelines is 11mm Static fibre ropes or 5mm galvanised steel rope. Using dynamic fibre ropes can give rise to 'bouncing' which is uncomfortable for the casualty.



When raising or lowering the Slix Stretcher there must be separate lifeline for security in the event of a main rope failure.

All the Slix range of Stretchers conform to
CE 93/42/EEC CLASS 1

All components supplied are manufactured to the relevant standards.

It is the users duty to ensure that any other item of equipment conforms to the relevant standard.

Identifying components of the Slix100 Stretcher & Spinal Slint



Loading and Securing a casualty into the Slix100 Stretcher

The Slix Stretcher should be stored and transported in a Carry Bag.

Remove the Slix Stretcher from the Carry Bag, undo the securing strap and unroll.

Lay on a flat surface, as close to the casualty as is possible, with the Carry Handles down. The head of the Stretcher should be level with the head of the casualty.

If using a spinal splint:

Place the Slix Spinal Splint onto the Slix Stretcher and attach it to the Spinal Splint Plate with the two fitted straps provided, Item 100SSA page 3. Place the casualty on the Stretcher with the head located to the top of the Spinal Splint and centrally positioned.

OR

If the casualty is loaded onto the Spinal Splint away from the Stretcher, move the casualty carefully into the Stretcher and attach the Spinal Splint to the Stretcher.

Fit the Foot Loops, Item 100FL, to the casualties feet, (do not remove footwear), crossing the straps over, and adjust buckles. If leg injuries are present it may be necessary to omit one or both Foot Loops.

Starting at the foot, secure the 4 Closure Straps, Item 100MCS, across the Stretcher and tighten securely, but be careful not to over tighten. Pay particular attention to the Closure Straps at the chest so respiration is not impaired.

Secure the ends of the Closure Straps so they do not present a snag hazard. Tucking ends in is the easiest option.

It is recommended that the casualties' arms are inside the Stretcher skin.

Feed the Foot Closure Straps, Item 100FCS, through the small eyelet and back through the buckle. Adjust until the rollover curves up to reveal the foot carry handle (100FCH). Allowance should be made if a leg splint is fitted.

When using a training mannequin - do not tighten beyond the label sewn to the strap.

The casualty is now secure and evacuation may begin.

Fitting Vertical Haul Lines to Slix Stretchers



Rope



Wire



Webbing



Pictured Left - 'Head Up' Horizontal Lift
(Green to Green & Blue to Blue)
To achieve a near horizontal lift, invert the stretcher stops, so the connectors attach Blue to Green & Green to Blue.

Pictured Below - Patient securely strapped into the SLIX100 (excluding spinal splint)



Inspection and Cleaning of The Slix 100 Stretcher

After each use the Slix 100 stretcher should be cleaned and inspected for damage by a competent person.

It is important that the stretcher and ancillary equipment is stored ready for use.

IF ANY CLOSURE OR STRETCHER STROPS HAVE BEEN IN CONTACT WITH ANY CHEMICAL, SOLVENT, ALKALINE, ACID OR ANY CONTAMINANT WHICH MAY DEGRADE POLYETHYLENE, POLYESTER OR NYLON THE STRETCHER AND/OR HAULING STROPS MUST NOT BE USED UNDER ANY CIRCUMSTANCES.

IF THE STRETCHER HAS BEEN SUBJECT TO A DROP ONTO THE VERTICAL OR HORIZONTAL HAULING POINTS DURING A PRACTICE OR A INCIDENT THE STRETCHER MUST BE INSPECTED, BY A COMPETENT PERSON IMMEDIATELY AND BEFORE FURTHER USE.

Refer to Page 3-part identification.

Oil, grease, blood, body fluids or non aggressive contaminants may be removed with warm- not hot- water and soap.

If a power washer is available, it may be used with care. After cleaning rinse thoroughly with clean water, hang vertically and allow to dry in a warm, dry atmosphere.

DO NOT APPLY HEAT.

Inspect Hauling webbing StroPs for physical or chemical damage. The integrity of the Hauling StroPs is essential and particular attention should be given to the stitching and the loop section of the StroPs for wear. If any damage is present DO NOT USE. Replace damaged Hauling StroPs immediately.

Inspect all Closure StroPs, Closure Buckles, Head & Foot Closure StroPs, Carry Handles, Adjustable Foot Loops and Buckles and Head & Side Grab Handles for physical or chemical damage. Damaged StroPs may be replaced. Contact the manufacture for replacements. DO NOT USE THE STRETCHER before changing damaged StroPs.

Inspect the Vertical Hauling Plate / Spinal Splint attachment point located at the head of the stretcher, for damage and / or distortion. Inspect the area of stretcher around the Vertical Hauling Plate and the Horizontal Attachment Points. If any distortion or splitting in the stretcher skin is found DO NOT USE.

IF IN ANY DOUBT ABOUT THE INTEGRITY OF THE SLIX100 STRETCHER PLEASE CONTACT THE MANUFACTURER.

Storage of the Slix 100 Stretcher and Spinal Splint

The Stretcher and Spinal Splint must be stored in the Carry Bag in a dry place out of direct sunlight.

It is good practice to seal the bag after the kit has been inspected and packed. A tear- off, non replaceable, type of closure should be threaded through the top of the Carry Bag.

Sealing the Carry Bag discourages tampering or pilfering and the rescuers are assured that the contents are present in the event of an incident.

The inspection, cleaning and packing of the Stretcher and Spinal Splint should be undertaken by a competent person and logged.

Abtech Safety Ltd recommends that a detailed inspection, should take place at 6 monthly intervals and the inspection logged by a competent person.

For further information or advice contact:



Certification



Abtech Safety Ltd
Units 1&2 Parkway Business Centre
Sixth Avenue, Zone 2
Deeside Industrial Estate
Flintshire
CH5 2LE

Tel: +44(0)1244 837 050
Fax: +44(0)1244 837 051
sales@abtechsafety.com
www.abtechsafety.com

DECLARATION OF CONFORMITY

This equipment conforms to CE 93/42/EEC CLASS 1 and is covered by European Council Directive 93/42/EEC CLASS 1 DEVICE. This equipment is registered with the Competent Authority (UK and conforms to article 11 (5) annex VII section 3.

We at Abtech Safety Ltd declare that the equipment described in this manual has been inspected in accordance with Abtech Safety Limited's quality assurance system BSEN ISO 9001:2015, under the supervision of the notified body number 0321 and unless otherwise stated complies with the full requirements of the specifications and contract/order at the time of manufacture.

SIGNED

A handwritten signature in black ink, appearing to be "A. J. Smith", written over a circular stamp.

