

Art. 204047

Assembly instructions

PROTOS® Actioncam-Bracket with Safety Loop



- ① Slide the ventilation slider backwards (closed ventilation openings) and lift it slightly at the front with the putty supplied, gently pressed downwards ①a, so that the safety loop can be inserted without having to remove the ventilation slider.
- ② The PROTOS® Actioncam-Bracket can now be placed in the intended position on the outer surface. The small edge (transition from the ventilation slider to the outer shell) serves as a stop aid. It is important that the PROTOS® Actioncam-Bracket is positioned exactly in the centre of the shell and completely against the stop.
- ③ When the position is exactly right, remove the red protective film and tilt it forward.
- ④ Press firmly over the entire adhesive surface for about 5 seconds. 80% of the holding force is reached after approx. 20 minutes, and full final holding force after approx. 72 hours.

Please note: If the double-sided adhesive comes into contact with the surface, it can hardly be removed even after a few seconds of contact!



If desired, your authorised PROTOS® dealer will be happy to install the PROTOS® Actioncam-Bracket with Safety Loop.

The PROTOS® Actioncam-Bracket is also suitable for attaching, for example, the PROTOS® Lupine helmet light.

PROTOS®