

Camshaft Mounting Tool Set | for VAG and Porsche



Product number: 9319

Weight: 9.5 kg

EAN: 4026947093192

- for installation camshafts in the correct position
- required when installing new or existing camshafts, an installation without this tool can cause damage to the camshaft bearing bridge and cylinder head
- suitable for the following diesel vehicles (TDI CR) as of 2003 Audi, Porsche, Seat, Skoda, Volkswagen with 1.2 1.6 2.0 2.7 3.0 4.0 4.2 Common-Rail engines
- engine codes: ASB, ASE, BKN, BKS, BMK, BNG, BPP, BSG, BTR, BUG, BUN, BVN, CAAA, CAAB, CAAC, CAAD, CAAE, CAGA, CAGB, CAGC, CAHA, CAHB, CAMA, CAMB, CANA, CANB, CANC, CAND, CAPA, CARA, CASA, CASB, CASC, CASD, CATA, CAYA, CAYB, CAYC, CAYD, CAYE, CBAA, CBAB, CBAC, CBBA, CBBB, CBDA, CBDB, CBDC, CCFA, CCFC, CCHA, CCHB, CCLA, CCMA, CCWA, CCWB, CDBA, CDCA, CDSB, CDTA, CDTB, CDUC, CDUD, CDYA, CDYB, CDYC, CEGA, CEXA, CFCA, CFFA, CFFB, CFFD, CFFE, CFGB, CFGC, CFGD, CFHA, CFHB, CFHC, CFHD, CFHE, CFHF, CFJA, CFWA, CGKA, CGKB, CGLA, CGLB, CGLC, CGLD, CGLE, CGQB, CJAA, CJCA, CJCB, CJCC, CJCD, CJGA, CJGC, CJGD, CJMA, CKDA, CKTB, CKTC, CKUB, CKUC, CKVB, CKVC, CLAA, CLAB, CLCA, CLCB, CLJA, CLLA, CLNA, CLZB, CMEA, CMFA, CMFB, CMGB, CMHA, CNEA, CNFA, CNRB, CRCA, CSHA, M05/9D (CAS), M05/9E, M05/9E (CRCA), M05/9E (CRCB)

scope of delivery:

- mounting device including pre-assembled parts, to be used as OEM T40094
- camshaft retaining clamp, to be used as OEM T40095
- 2 alignment clamps, to be used as OEM T40096 & T40096/1
- 4 camshaft brackets for mounting device, to be used as OEM T40094/1, T40094/2, T40094/9, T40094/10
- locking tool for camshaft holder, to be used as OEM T40094/11