

15-20L ALL PACK 2.0

29-00363B



FEATURES

- * A lightweight backpack that can be used in many different ways.
- * It has MOLLE bands on the outside.
- * Outside Velcro stripes so you can attach your markings.
- * The pack can be attached to our other backpacks, on our ballistic and non equipment vests. It can also be carried on its own.
- * It is expandable from 15-20S L with an expansion zipper.
- * Openings for cables and hydration systems in the top.
- * Inside hanger for a hydration system.
- * Outside compartment with zipper closure.
- * Inside covered with Velcro loop fabric so pouches can be attached.

DIMENSIONS

H=50, W=31 & D=10-15 cm.

WEIGHT

860 g.

MATERIAL

Fabric: 100% polyamide PU coated

Webbing: 100% polyester.

SWEDISH ARMY STOCK NUMBER

M7085-823010

RYGGSÄCK 15-25L



SNIGEL

PRODUCT SHEET- 15-20L ALL PACK 2.0B

15-20L ALL PACK 2.0

29-00363B



All parts in the backpack:
Two Duffel straps.
One backpack w internal plastic sheet frame.
Two shoulder pads.



The shoulder pads can be removed from the backpack.
This is convenient when you attach the All pack to our plate carrier/ballistic vest.



The shoulder pads can also be secured under the horizontal webbing on the back of the AllPack.



We have introduced a new buckle, the "Herma buckle".
This is a brilliant buckle that always fits, no more Male or Female buckles, just one that matches it self.



The inside is covered with Velcro loop fabric. Our insert pouches can be attached there.



Insert pouches attached inside the All pack.



The All pack can be expanded to 20L volume.
Open the zipper along the sides.



The AllPack can be attached to the Squeeze vest with the Gate keeper buckle.
The carry straps are used as a waist strap to prevent bouncing.



Detail showing how the buckle is connecting the AllPack and the Squeeze.

ATTACHING IT TO SQUEEZE

WITH DUFFEL STRAPS



The All pack attached with a pair of Duffel straps with Herma buckles and herma repair buckles (not included) and the enclosed duffel straps is used as a waist band.



Parts used:
26-00428-09-000, Duffel strap set
01-200-09, Herma 25 mm buckle pair
01-202-09, Herma 25 mm repair buckle pair.



1. Remove the shoulder pads from the AllPack.
The shoulder pads can also be secured under the 8 mm webbing on the back of the AllPack.



2. Remove the side release buckles from the duffel straps.



3. Attach duffel straps to the AllPack
4. Attach the Herma 25 mm buckle to the duffel strap.
5. Attach the roll up ends and shorten the straps.



6. Attach the Herma 25 mm repair buckle pair on the Squeeze.



7. Connect the duffel straps from the AllPack to the repair buckles on the Squeeze.
8. Close the adjustment straps from the AllPack as a waist strap.



Detail of the connection between the AllPack and the Herma buckle on the Squeeze.



When attached with Duffel straps, one Duffel strap can be connected with the vest. In this configuration the All pack can be accessed and still be connected.