

For reverse light or other functions where the response time is not critical (or in the same area as the cabin).



(Vehicle only for illustration).

For optimal response time, place the XBB PowerUnit as close as possible to the XBB Dongle.
(Where fast response time is critical, e.g auxiliary lights and high beam signal).



	Innoware Development AB		
	Hyttvägen 13 733 38 SALA		
FILENAMN	DATE	2020-10-19	Ver 1.0
SCHEMANAMN	RIT	JB	SCHESUMMER