

ALWAYS CHECK THE OIL LEVEL WITH THE LIFTING ARM IN THE LOWEST POSITION

Type

Litre

Type of oil

Alternative

Correct oil level

Air connection

Catalogue models

Jacks, manual

2T-C (G3)

0,50

CASTROL - AWS 22

10 mm under the refilling hole

2T-F (G3)

0,50

CASTROL - AWS 22

10 mm under the refilling hole

3T-C (G4)

0,50

CASTROL - AWS 22

10 mm under the refilling hole

4T-C (G4)

0,90

CASTROL - AWS 22

10 mm under the refilling hole

5T-C (G3)

0,90

CASTROL - AWS 22

10 mm under the refilling hole

6T-C (G3)

1,00

CASTROL - AWS 22

10 mm under the refilling hole

8T-C (G3)

0,90

CASTROL - AWS 22

10 mm under the refilling hole

10T-C (G3)

0,90

CASTROL - AWS 22

11 mm under the refilling hole

15T-C (G1)

2,60

CASTROL - AWS 22

10 mm under the refilling hole

20T-C (G1)

2,25

CASTROL - AWS 22

10 mm under the refilling hole

1.5T-HC (G3)

0,50

CASTROL - AWS 22

10 mm under the refilling hole

2T-HC (G3)

0,70

CASTROL - AWS 22

10 mm under the refilling hole

3T-HC (G3)

0,90

CASTROL - AWS 22

10 mm under the refilling hole

5T- HC (G1)

2,50

CASTROL - AWS 22

10 mm under the refilling hole

8T-HC (G2)

2,50

CASTROL - AWS 22

10 mm under the refilling hole

10T-HC (G4)

2,50

CASTROL - AWS 22

10 mm under the refilling hole

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
<u>Jacks, air hydraulic</u>					
A28-HC (G1)	1,20	CASTROL - ATF DEX II		Up to the edge of the refilling hole	8 -12 bar
A3216-C (G1)		CASTROL - ATF DEX II		Up to the edge of the refilling hole	8 -12 bar
A4020-C (G1)		CASTROL - ATF DEX II		Up to the edge of the refilling hole	8 -12 bar
A5816-C (G1)		CASTROL - ATF DEX II		Up to the edge of the refilling hole	8 -12 bar
A5830-C (G1)		CASTROL - ATF DEX II		Up to the edge of the refilling hole	8 -12 bar
<u>Foot operated presses</u>					
FP16 (G2)	1,40	CASTROL - AWS 22	CASTROL - AWS 32		
FP20 (G5)	2,25	CASTROL - AWS 22			
FP25 (G5)	2,25	CASTROL - AWS 22			
FP40 (G1)	4,00	CASTROL - AWS 22			
FP50 (G2)	4,00	CASTROL - AWS 22			
<u>Hand operated presses</u>					
HP20 (G6)	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
HP25 (G6)	2,25	CASTROL - AWS 22			
HP40 (G1)	4,00	CASTROL - AWS 22	CASTROL - AWS 32	110 mm under the refilling hole	
HP50 (G2)	4,00	CASTROL - AWS 22	CASTROL - AWS 32	80 mm under the refilling hole	
HP60 (G1)	5,00	CASTROL - AWS 22			
HP70 (G1)	6,00	CASTROL - AWS 22			
HP100 (G3)	6,00	CASTROL - AWS 22	CASTROL - AWS 32	50 mm under the refilling hole	
HP100F (G2)					

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
<u>Electro-hydraulic presses</u>					
EP40	15,00	CASTROL - AWS 32			
EP40 D	15,00	CASTROL - AWS 32			
EP60	18,00	CASTROL - AWS 32			
EP60 D	18,00	CASTROL - AWS 32			
EP100 D	27,00	CASTROL - AWHM 46			
EP100 D F	30,00	CASTROL - AWHM 46			
<u>Other presses</u>					
AP20 (G6)	1,50	CASTROL - AWS 10		25 - 70 mm under the refilling hole	6 - 8 bar
CSC (G2)	0,00	No oil in machine	No oil in machine	No oil in machine	
<u>Bottle jacks</u>					
CBJ 3	0,09	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 5	0,15	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 10	0,24	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 15	0,34	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 20	0,47	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 25	0,49	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 30	0,55	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 50	0,85	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ-T4	0,15	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ-T10	0,65	CASTROL - AWS 22		Up to the edge of the refilling hole	

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
<u>Cranes</u> CC055 (G3) CC10 (G4) CC15P	 0,80 1,50	CASTROL - AWS 32 CASTROL - AWS 32 CASTROL - AWS 32		10 mm under the refilling hole Up to the edge of the refilling hole Up to the edge of the refilling hole	
<u>Transmission jacks</u> TJ300 (G1) TJ325 / TJ325 (G2) TJ525 / TJ525 (G2) TJ1000 (G2) TJ-T1300 (G3) TJ-T2000 (G2)	0,95 0,95 0,95 0,95 2,80 0,95	CASTROL - AWS 32 CASTROL - AWS 32 CASTROL - AWS 32 CASTROL - AWS 32 CASTROL - AWS 32 CASTROL - AWS 32		Up to the edge of the refilling hole Up to the edge of the refilling hole Up to the edge of the refilling hole Up to the edge of the refilling hole Up to the edge of the refilling hole	
<u>Wheel dollies</u> WD Mobile WD 60 (G2) WD 800 WD 1500 (G3)	0,00 0,95 0,50 0,80	No oil in machine CASTROL - AWS 22 CASTROL - AWS 22 CASTROL - AWS 22	No oil in machine	No oil in machine 10 mm under the refilling hole 10 mm under the refilling hole 10 mm under the refilling hole	
<u>Hydraulic body repair kits</u> CRK 4 CRK 10	0,50 0,50	CASTROL - AWS 22 CASTROL - AWS 22		Under the refilling hole Under the refilling hole	

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
<u>Old models</u>					
<u>Jacks, manuel</u>					
1T-2H	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,3T-H	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-1HL; 1,5T-2HL	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-2	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-2S	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-C	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-H	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-HA	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5TH-LJ	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-H-US	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-LJ	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-1B	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-1V	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-2HA	0,70	CASTROL - AWS 22		10 mm under the refilling hole	
2T-2HA-B	0,70	CASTROL - AWS 22		10 mm under the refilling hole	
2T-2L	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-2LS	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-2Q	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-4A	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-4B	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-4K	0,50	CASTROL - AWS 22		10 mm under the refilling hole	

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
2T-4KS	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-4Q	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-4Q-TE	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-5H	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
2T-Au	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-LF	0,70	CASTROL - AWS 22		10 mm under the refilling hole	
2T-LF2	0,70	CASTROL - AWS 22		10 mm under the refilling hole	
2TK-5	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-LJ	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2TQ-LJ	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2TQ-LJ-TE	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-V; 2T-V-Boogie	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2,25T-2L	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2,25T-4K	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2,5T-1	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2,5T-4K	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2,5T-4Q	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2,5T-5H	1,00	CASTROL - AWS 22		10 mm under the refilling hole	
3T-1B	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
3T-5H	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
3T-V	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
4,5T-4	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
4T-4	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
5T-2QA	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
5T-3Q-US-2	0,90	CASTROL - AWS 22		10 mm under the refilling hole	

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
6T-2H	1,40	CASTROL - AWS 22		10 mm under the refilling hole	
6T-4	1,00	CASTROL - AWS 22		10 mm under the refilling hole	
6T-K	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
6T-HC	1,40	CASTROL - AWS 22		10 mm under the refilling hole	
7,5T-2H	1,40	CASTROL - AWS 22		10 mm under the refilling hole	
7.5T-4	1,00	CASTROL - AWS 22		10 mm under the refilling hole	
8T-1	1,00	CASTROL - AWS 22		10 mm under the refilling hole	
10T-2A	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
10T-4	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
10T-4M	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
10T-4-US-3	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
10T-K	1,00	CASTROL - AWS 22		10 mm under the refilling hole	
10T-C (G1/G2)	2,50	CASTROL - AWS 22		10 mm under the refilling hole	
12T-2	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
15T-2	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
15T-2M	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
20T-1M	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
<u>Other jacks</u>					
ALU-C (G1/G2)	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
CFLJ-4	0,80	CASTROL - AWS 22		10 mm under the refilling hole	
CFLJ-5	0,80	CASTROL - AWS 22		10 mm under the refilling hole	

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
<u>Jacks, air hydraulic</u>					
A2-2; A3-2	0,50	CASTROL - AWS 22		65 mm under the refilling hole	8 - 10 bar
A2510-3; A2510-4	1,90	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar
A2510-C (G1/G4)	2,50	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar
A2510-C (G5)	2,50	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar
A4020-1	1,90	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar
A4411-C (G1/G4)	2,50	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar
A4411-C (G5)	2,50	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar
A4422-C (G1/G4)	3,50	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar
A4422-C (G5)	3,50	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 12 bar
AM5 1,5T-F	0,55	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 2,5T-5H	1,50	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 3T-C	0,55	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 3T-5H	1,50	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 4T-4	1,50	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 5T-3QA	1,50	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 5T-3Q-US-2	1,50	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 10T-2-US	2,50	CASTROL - AWS 22		30 mm under the refilling hole	8 - 10 bar
AM5 10T-4	2,50	CASTROL - AWS 22		30 mm under the refilling hole	8 - 10 bar
AM5 15T-2	2,50	CASTROL - AWS 22		30 mm under the refilling hole	8 - 10 bar
AM5 18T-1	2,50	CASTROL - AWS 22		30 mm under the refilling hole	8 - 10 bar
AM5-18T-2L	2,50	CASTROL - AWS 22		30 mm under the refilling hole	8 - 10 bar
AM5 20T-1-US	2,50	CASTROL - AWS 22		30 mm under the refilling hole	8 - 10 bar
AV20-2; A4020-2	1,90	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar
AV20-C (G1/G4)	3,00	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar
AV20-C (G5)	3,00	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar
AV22-2; AV20-3	1,90	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
<u>Foot operated presses</u>					
FP16 (G1)		CASTROL - AWS 22			
FP20-AA/AR	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	6 - 8 bar
FP20 (G2/G4)	2,25	CASTROL - AWS 22			
FP25 (G2/G4)	2,25	CASTROL - AWS 22			
FP50 (G1)	4,00	CASTROL - AWS 22			
<u>Hand operated presses</u>					
HP15	1,50	CASTROL - AWS 22	CASTROL - AWS 32		
HP20-AR	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
HP20-AA/AR	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	6 - 8 bar
HP20 (G2/G5)	2,25	CASTROL - AWS 22			
HP25	3,00	CASTROL - AWS 22	CASTROL - AWS 32		
HP25-1 (with 15T pump)	1,50	CASTROL - AWS 22	CASTROL - AWS 32		
HP25 Junior	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
HP25 (G2/G5)	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
HP50 (G1)	4,00	CASTROL - AWS 22			
HP100 (G1)	10,00	CASTROL - AWS 22	CASTROL - AWS 32	40 mm under the refilling hole	
HP125	10,00	CASTROL - AWS 22	CASTROL - AWS 32		

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
<u>Electro-hydraulic presses</u>					
EP25-1/ EP25-1D/ EP25-1D-3/ EP25-1D-4	14,00	CASTROL - AWS 32			
EP100-2/ EP100-2D-3/ EP100-2D-4 EP100-2D-320	27,00	CASTROL - AWS 32			
EP125-2/ EP125-2D-3/ EP125-2D-4	27,00	CASTROL - AWS 32			
EP(MP)150-2D-4	30,00	CASTROL - AWS 32			
EP40-1/ EP40-1D/ EP40-1D-3/ EP40-1D-4	14,00	CASTROL - AWS 32			
EP60-1	14,00	CASTROL - AWS 32			
EP60-2/ EP60-2D-3/ EP60-2D-4	27,00	CASTROL - AWS 32			
MDP10-1	14,00	CASTROL - AWS 32			
MPC10-1/ MPC10-1-H/ MPC10-1D/ MPC10-1D-3	11,00	CASTROL - AWS 32			
MPC25-1/ MPC25-1D/ MPC25-1D-3	11,00	CASTROL - AWS 32			
MPC40-1/ MPC40-1D/ MPC40-1D-3	11,00	CASTROL - AWS 32			
<u>Other presses</u>					
ABP20	1,50	CASTROL - AWS 10		25 - 70 mm under the refilling hole	6 - 8 bar
ADP10	1,50	CASTROL - AWS 10		25 - 70 mm under the refilling hole	6 - 8 bar
AP15	1,50	CASTROL - AWS 10		25 - 70 mm under the refilling hole	6 - 8 bar
AP20	1,50	CASTROL - AWS 10		25 - 70 mm under the refilling hole	6 - 8 bar
BP15	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
CSC (G1)	0,00	No oil in machine	No oil in machine	No oil in machine	
DP10-B2, DP6-B2	1,25	CASTROL - AWS 22	CASTROL - AWS 32		

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
<u>Jacking beams</u>					
JB20					
JB20-2					
JB20-3	0,50	CASTROL - AWS 22			
JB20-4					
JB20A-4					
JB20A-5	0,50	CASTROL - AWS 22		95 - 100mm - Safety stop i top position	8 - 10 bar
JB26-3	0,50	CASTROL - AWS 22			
JB26-4					
JB26A-4					
JB26A-5					
JB26A-5C	0,50	CASTROL - AWS 22		95 - 100mm - Safety stop i top position	8 - 10 bar
JB28-3					
JB28-4					
JB50A-1					
<u>Jacking beams</u>					
RLB20 (G1)					
RLB20A (G1)					
RLB22 (G1)					
RLB22A (G1)					
RLB26 (G1)					
RLB26A (G1)					
RLB28 (G1)					
RLB28A (G1)					
RLB30 (G1)					
RLB30A (G1)					
RLB-F					
RLB-H					

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
<u>Cranes</u> CC05/ CC05P; CC05-J CC055 (G1/G2) CC10L (G2/G3) K1 K05 K05-2 K15	0,80 0,80	CASTROL - AWS 32 CASTROL - AWS 32 CASTROL - AWS 32		Up to the edge of the refilling hole 10 mm under the refilling hole Up to the edge of the refilling hole	
<u>Transmission jacks</u> TJ-T750 TJ1000 (G1) TJ-T1300 (G2) TJ-T2000 (G1)	0,95 2,80	CASTROL - AWS 32 CASTROL - AWS 32 CASTROL - AWS 32		Up to the edge of the refilling hole Up to the edge of the refilling hole Up to the edge of the refilling hole	
<u>Wheel Dollies</u> WD 1500 (/G2) WD60 (G1)	0,80	CASTROL - AWS 22		10 mm under the refilling hole	
<u>Other models</u> CPT 22 CPT 25 PT25-C	0,75 0,75 0,75				

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
<p align="center"><u>Ugået Typer</u></p>					
MP 1 trins	14,00	CASTROL - AWS 22			
MP 2 trins	30,00	CASTROL - AWS 22			
TH 450 LH	0,2 ??	CASTROL - AWS 22		Up to the edge of the refilling hole	
650-1	2,00	CASTROL - AWS 22		Up to the edge of the refilling hole	
<p align="center">Viskositet 22 ved 40 grader</p>					
<p>Updated 140408</p>					