



Control Guide: When a command from the control is accepted by the light, the light will flash.

If the light does not flash then:

- Make sure you're in range (8-10ft).
 - Make sure the light is charged and/or connected to the solar panel.
 - Check the batteries in the remote (2x AAA included).
-
- **Auto:** Will automatically switch light **ON** when it is dark and **OFF** when it is light. To disengage the auto function, press the **OFF** button.
 - **On:** Turns light manually **ON**
 - **Off:** Turns light manually **OFF** and disengages **AUTO** and **TIMING** modes
 - **2H:** The light will come on when it is dark and stay on for **2 hours**
 - **4H:** The light will come on when it is dark and stay on for **4 hours**
 - **6H:** The light will come on when it is dark and stay on for **6 hours**
 - **8H:** The light will come on when it is dark and stay on for **8 hours**

Installation Guide:

- Using the included screws secure your light to its desired position.
- Using the included screws attach the solar panel to its desired position within the cable length of the light and in as much direct sunlight as possible.
- Connect the light to the solar panel using the 2-pin connector (the units are IP67 rated. However, it is still best to have the connector undercover if possible).