


ELENCO PEZZI DI RICAMBIO
 LISTE PIECES DETACHEES
 SPARE PARTS LIST
 ERSATZTEILLISTE
 PIEZAS DE REPUESTO

ALUCAR 5100



Esplodo macchina, Dessin appareil, Machine drawing, Explosions Zeichnung des Geräts, Diseño seccionado maquina.



REF.	ELENCO PEZZI DI RICAMBIO PIECES DETACHEES SPARE PARTS LIST ERSATZTEILLISTE PIEZAS DE REPUESTO	CODICE CODE KODE
1	Potenzometro Potentiometre Potentiometer Potenciometro	112017
2	Condensatore Condensateur Capacitor Kondensator Condensador	112688
3	Raddrizzatore monofase Redresseur monophasé Single-phase rectifier Einphasiger Gleichrichter Rectificador monofásico	112949
4	Rele' Relais Relais Relais	113493
5	Mosfet Mosfet Mosfet Mosfet	116813
6	Triac Triac Triac Triac Triac	116812
7	Rele Relais Relais Relais Conectador	116822
8	Scr Scr Scr Scr Scr	116825
9	Manopola per potenziometro Poignée pour potentiometre Knob for potentiometer Griff fuer potentiometer Manija para potenciometro	121043
10	Microinterruttore Microinterrupteur Microswitch Microschalter Micro interruptor	122393
11	Fusibile Fusible Fuse Sicherung Fusible	122434

REF.	ELENCO PEZZI DI RICAMBIO PIECES DETACHEES SPARE PARTS LIST ERSATZTEILLISTE PIEZAS DE REPUESTO	CODICE CODE KODE
12	Interruttore Interrupteur Switch Schalter Interruptor	122477
13	Microinterruttore Microinterrupteur Microswitch Microschalter Microinterruptor	122777
14	Cavo 16 mmq 3 m Cable 16 mmq 3 m Cable 16 mmq 3 m Kabel 16 mmq 3 m Cable 16 mmq 3 m	123443
15	Cavo 25 mmq 4 m Cable 25 mmq 4 m Cable 25 mmq 4 m Kabel 25 mmq 4 m Cable 25 mmq 4 m	123468
16	Assieme cavo pistola Cable + pistol set Gun + cable set Pistole + kabel set Cable + pistola	124197
17	Cavo alim. H05vv-f 3g01.50 L=02.30 Cable alim. H05vv-f 3g01.50 L=02.30 Mains cable h05vv-f 3g01.50 L=02.30 Netzkaabel h05vv-f 3g01.50 L=02.30 Cable alim. H05vv-f 3g01.50 L=02.30	132360
18	Trasformatore impulsi Transformateur pulsee Pulse transformer Pulse transformator Transformador pulsado	152247
19	Trasformatore di potenza Transformateur de puissance Power transformer Leistungstransformator Transformador de potencia	169648
20	Trasformatore ausiliario Transformateur auxiliaire Auxiliary transformer Hilfstrafo Transformador ausiliario	169650
21	Retro Partie arriere Back panel Rueckseite Trasera	322694
22	Manico Poignée Handle Handgriff Manija	322695

REF.	ELENCO PEZZI DI RICAMBIO PIECES DETACHEES SPARE PARTS LIST ERSATZTEILLISTE PIEZAS DE REPUESTO	CODICE CODE KODE
23	Frontale Partie frontal Front panel Geraetefront Frontal	322792
24	Toledo 300 pinza di massa 300a Toledo 300 borne de masse 300a Toledo 300 work clamp 300a Toledo 300 masseklemme 300a Toledo 300 borne de masa 300a	712231
25	Dado Ecrou Nut Mutter Tuerca	742256
26	Kit pressacavo Kit presse-cable Cable - bushing kit Kabelhalter kit Kit prensa cable	980259
27	Kit fondo Kit chassis Bottom kit Bodenteil kit Kit fondo	980826
28	Kit mantello Kit capot Cover kit Deckelkit Kit panel de cobertura	980827
29	Kit scheda completa Kit platine complete Complete module kit Komplette karte kit Kit tarjeta completa	980828
30	Kit pressacavo + dado Kit presse-cable + ecrou Kit cable bushing + nut Kit kabelhalter + mutter Kit prensa cable + dado	990152
31	Kit impugnatura Kit poignée Knob kit Griffkit Kit manija	990781
32	Resistenza Resistance Resistance Widerstand Resistencia	116830

Esploso macchina, Dessin appareil, Machine drawing, Explosions Zeichnung des Geräts, Diseño seccionado maquina.

Schema elettrico, Schéma électrique, Diagram, Schaltplan, Esquema de conexiones.

