


Flylink-01 Code-pairing Procedures:

1. Connect the projector and the power with the Flylink-01, turn the projector on, then press and hold the Flylink-01 Button, let your hand go until its indicator light flashes 6 times and off.
2. Press the Manual Switch Button to let the fabric go down for about 20cm, then stop it. (This procedure is for getting a better view on the motion of the screen only)
3. Press and hold the Manual Switch Button for about 3 seconds. Then the screen will go up and down for one time. Let your hand go and the screen is ready to pair the code.
4. Press the button with a needlelike pin in the Flylink-01 meanwhile the screen will go up and down for one time. This shows that the code has been paired successfully.
5. If the Flylink-01 button is failed to be pressed within 8 seconds in Procedure 4, then above code pairing operations will be cancelled.



Manual Switch Button

Indicator Light

Flylink-01 Button

