


Pool Volleyball Assembly Instructions

Set Includes:

- 1-5/8" 2-piece telescopic PVC poles
- 3'x24' Sport level aqua volleyball net
- Support bases - fillable with sand or water
- 2- 10" anchors for net tension
- 2- 15' Net tension adjuster cords
- Telescopic heights above pool side: 24", 34", 38" and 42"



Adult assembly and supervision required.


Base and Pole Set-up

The support bases can be filled with water or sand. Position the bases on either side of the pool playing area. Insert lower pole section securely into the base. Adjust pole to desired playing height.



Net Assembly

Insert the rope cable through the net clip on the pole. Wrap top rope cable around the pole and through the grommet hole in the top corner of the net. Tie a double knot on the backside of the grommet to keep the rope from slipping. Tie the bottom net cords around the lower pole keeping the net sides parallel to the poles.



If additional net tension or outward stability is required, use the 15' adjuster cords and ground stakes. Do not over tension the poles. Keep the poles in a tight, upright position.




Note: net width can be adjusted to a shorter length by rolling excess netting onto the support pole.

Pool Volleyball Assembly Instructions

Set Includes:

- 1-5/8" 2-piece telescopic PVC poles
- 3'x24' Sport level aqua volleyball net
- Support bases - fillable with sand or water
- 2- 10" anchors for net tension
- 2- 15' Net tension adjuster cords
- Telescopic heights above pool side: 24", 34", 38" and 42"



Adult assembly and supervision required.


Base and Pole Set-up

The support bases can be filled with water or sand. Position the bases on either side of the pool playing area. Insert lower pole section securely into the base. Adjust pole to desired playing height.



Net Assembly

Insert the rope cable through the net clip on the pole. Wrap top rope cable around the pole and through the grommet hole in the top corner of the net. Tie a double knot on the backside of the grommet to keep the rope from slipping. Tie the bottom net cords around the lower pole keeping the net sides parallel to the poles.



If additional net tension or outward stability is required, use the 15' adjuster cords and ground stakes. Do not over tension the poles. Keep the poles in a tight, upright position.



Note: net width can be adjusted to a shorter length by rolling excess netting onto the support pole.