


Injector Extractor Set | for Trucks



TOOLS

- | | | | |
|---|-------------------|---|-----------------------|
| 1 | Joint | 4 | Handle |
| 2 | Adapter M18 x 1.5 | 5 | Sliding hammer weight |
| 3 | Pulling Hook | 6 | Sliding hammer shaft |

ATTENTION

Read the operating instructions and all safety instructions contained therein carefully before using the product. Use the product correctly, with care and only according to the intended purpose. Non-compliance of the safety instructions may lead to damage, personal injury and to termination of the warranty. Keep these instructions in a safe and dry location for future reference. Enclose the operating instructions when handing over the product to third parties.

SAFETY INFORMATIONS

WARNING! Ensure Health and Safety, local authority and general workshop practice regulations are adhered to when using tools.

WARNING! Always use caution when working around fuel systems. The fuel in the fuel rail may be pressurised even if the engine is not running.

IMPORTANT: These instructions are provided as a guide only.


- Always refer to the vehicle manufacturer's service instructions, or a proprietary manual, to establish the current procedure and data, also any warnings or cautions particular to the vehicle.
- DO NOT use the set if any parts are missing or damaged.
- DO NOT use this tool for any purpose other than that for which it is designed.
- Switch off vehicle's ignition and disconnect the battery before commencing work under the bonnet.
- You must follow the vehicle's service manual cautions when working around the air bag system. If the cautions are not followed the air bag may deploy unexpectedly even after the ignition is turned 'OFF', resulting in personal injury.
- Never lay tools on the vehicle's battery. This may short the terminals together, causing harm to yourself, the tools, or the battery.
- Operate in a well ventilated area. Do not inhale fuel vapours.
- Wear approved eye protection.
- Wear suitable clothing to avoid snagging. Do not wear jewellery and tie back long hair.
- Keep children and other unauthorised persons away from the working area.
- Keep yourself, tools, and test equipment away from hot engine parts.
- Always keep a fire extinguisher close by, that is suitable for fuel electrical or chemical fires.
- NEVER smoke or have open flames near vehicle.
- Always relieve fuel pressure before disconnecting fuel lines from injectors.
- Use a rag to cover fuel line fittings, when connecting or disconnecting fuel lines. Avoid contact with fuel.
- Clean up all fuel spills immediately and dispose of all rags properly.
- Maintain the tool components in good and clean condition for best and safest performance.
- When work on the vehicle is finished, ensure all connections on vehicle are restored, and that there are no tools left in the engine bay.
- Replace tools in the carrying case and store in a safe, dry, childproof location.

INTENDED USE

This tool set is used for dismantling injectors on trucks with pump nozzle systems (e.g. Delphi) and with conventional injectors, installed in e.g. Volvo, Scania, Mercedes, Man, Renault and Iveco.

USAGE EXAMPLES

- 1 Joint
- 2 Adapter M18 x 1.5
- 3 Pulling hook
- 4 Handle
- 5 Sliding hammer weight
- 6 Sliding hammer shaft
- A Injector



NOTES

ENVIRONMENTAL PROTECTION

Recycle unwanted materials instead of disposing of them as waste. Packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. Contact your local solid waste authority for recycling information. Dispose of this product at the end of its working life environmentally.

