

SRV-110 STICKSÄG

1	S-100-01	Front	17	S-100-17	Kula
2	S-100-02	Styrning	18	S-100-18	Cylinder
3	S-100-03	Skruv	19	S-100-19	Stoppring
4	S-100-04	Låsskruv	20	S-110-20	O-ring
5	S-100-05	Rikthylsa	21	F-110-21	Ventil
7	S-100-07	Stång m. kuts	22	S-100-22	Kolvring
8	S-100-08	Fjäder	23	S-100-23	Böjd cylinder
9	S-100-09	Fjäder	24	S-100-24	Ringspärr
10	S-100-10	Hylsa	25	S-100-25	O-ring (2)
12	S-100-12	Kolv	26	F-110-26	Ventilfjäder
13	S-100-13	Kolvring	27	S-100-27	Spännstift
14	S-100-14	Begränsare	28	S-110-28	Inloppsdel
15	S-110-15	Trycke	29	S-100-29	Nyckel, hex

