














Turntables without RIAA amplifier -

Can be used with Phono Amplifier MK2 for B&O



Product	Image	Year
Beogram 1000V	 A top-down view of a Beogram 1000V turntable. It features a black platter with a white center, a silver tonearm, and a black dust cover. The turntable is mounted on a wooden base.	1966-72
Beogram 1001	 A top-down view of a Beogram 1001 turntable. It has a black platter with a white center, a silver tonearm, and a black dust cover. The turntable is mounted on a wooden base.	1973-74
Beogram 1100	 A top-down view of a Beogram 1100 turntable. It features a silver platter with a black center, a silver tonearm, and a silver dust cover. The turntable is mounted on a wooden base.	1976-77
Beogram 1102	 A top-down view of a Beogram 1102 turntable. It has a silver platter with a black center, a silver tonearm, and a silver dust cover. The turntable is mounted on a wooden base.	1978
Beogram 1200	 A top-down view of a Beogram 1200 turntable. It features a silver platter with a black center, a silver tonearm, and a silver dust cover. The turntable is mounted on a wooden base.	1969-72
Beogram 1201	 A top-down view of a Beogram 1201 turntable. It has a silver platter with a black center, a silver tonearm, and a silver dust cover. The turntable is mounted on a wooden base.	1973

Product	Image	Year
Beogram 1202		1974-75
Beogram 1203		1974-76
Beogram 1204		1976
Beogram 1500		1968-74
Beogram 1700		1979-82
Beogram 1800		1971-73
Beogram 1800 VF		1968-69
Beogram 1900		1976
Beogram 1902		1977-78

Product	Image	Year
Beogram 2000		1975-77
Beogram 2000 RD		1983-87
Beogram 2200		1979-80
Beogram 2202		1981
Beogram 2400		1979-80
Beogram 2402		1981
Beogram 2404		1980-83



Product	Image	Year
Beogram 3000		1967-68
Beogram 3000		1972-75
Beogram 3000		1985-87
Beogram 3300		1987-90
Beogram 3400		1975-77
Beogram 3404		1980-82
Beogram 4000		1974-75





Product	Image	Year
Beogram 4001		1977-80
Beogram 4002		1975-79
Beogram 4004		1978-80
Beogram 5000		1983-86
Beogram 5005		1985-87
Beogram 5500		1987-89
Beogram 6002		1983-86

Product	Image	Year
Beogram 6006		1981-82
Beogram 8000		1981-82
Beogram 8002		1982-87
Beogram 8500		1990-93
Beogram 9000		1988-90
Beogram 9500		1989-93
Beogram RX		1983-86

Product	Image	Year
Beogram RX2		1985-91
Beogram TX		1983-85
Beogram TX2		1985-91

B&O Turntables with RIAA amplifier built-in- cannot be used with external RIAA

Model	Image	Year
Beogram 1000VF		1965-73
Beogram 1200 with GF3		1968-73

Model	Image	Year
Beogram 3000 with GF4		1968
Beogram 3400 Quad		1975-77
Beogram 3500		1990-93
Beogram 4500		1988-91
Beogram 6000		1974-78
Beogram 6500		1989-91
Beogram 7000		1992-96