

Ditec Tar & Glue Remover

Removes tar & glue from all surfaces

Fields of application

Ditec Tar & Glue Remover is used to remove tar & glue residues on hard and soft surfaces.

Advantages

- pH-neutral
- Can be used on most surfaces without causing damage
- Gives fast results

Application instructions

Spray Ditec Tar & Glue Remover directly on the surface where tar or glue residues are present and leave to work for 1-5 min. Use a plastic scraper to remove to dissolve the residues. For thicker residues layers, let the product work longer. Finish the work through to clean the surface with a damp cloth or glass cleaner /APC. Check that the material is durable the product. Shake before use.

Dosage

Use in concentrated, do not dilute

Packaging

Unit	Itemnumber
0,5L	20-11005
5L	20-1105



The product image should be seen as an illustration. Some deviation from reality may occur.

MSDS

Safety Data Sheet is available in ditecshop.com or upon request.

Safety

Wear protective gloves, protective clothing, eye protection, face protection.