BATO 65097 USER MANUAL



3W COB LED HEADLIGHT



General Safety Instructions:

1.Never look directly into the LED light Source.

2. Must not be immersed in water or other liquids.

3. Must not be operated with wet hands

4. Must never be covered.

5. Must never be operated with an open housing, missing or damaged wiring compartment, or missing or damaged lens.

6.Must never be sprayed or cleaned using a steam pressure cleaner since this can damage the insulation and seals.

7. Must never be repaired by the user, repairs must only be carried out by the manufacturer or an authorized service representative.

Features:

Motion activated sensor (Hand Wave) Wireless speaker for phone calls / play music Adjustable headband to fit any head size Type-C USB Charging 5V-1A

IPX4

Technical Data:

LED: 3W COB Brightness: COB: 350 / 120 lumens Battery: Li-ion 3.7V 1200mAh Working Time: COB: 2.5/3.5 hrs Flash: 2-4hrs Charging Time: 3 hrs

Commissioning:

- Short press once on the On/Off switch to go to the next setting, the following setting are possible: COB Full power- COB Half power- Flash Light - OFF.

- Short press the sensor switch to activate the motion sensor function, hand wave to turn on or turn off the light.

- Long press the sensor switch to activate the wireless speaker function, connect the phone to pick up the call by hand wave once, hang up the call by hand wave twice.

- Play music and control the volume by phone.

- Speaker function will automatically disconnect if it is not used for a long time.

Note:

All light are partially charged when delivered.

Charge the product before use fully.

Please do not use the light when charging.

Please do not leave the lamp be in charging over 24 hours.

Please do not disassemble the lamp.

Please recharge the lamp every six months when in stock.

Cleaning:

Allow the light to cool down sufficiently!

Clean with a dry or slightly moist, clean, lint-free cloth and a mild detergent if required.

Do not use cleaners that contain abrasives or solvents.