



Säkerhetsventil 09101

Denna 6,0 bars säkerhetsventil 09101 är monterad på Isotemp Basic, Slim/A, Slim/B och Slim Square i produktion fram till senhösten 2006.

Vid byte av säkerhetsventil, rengör gängan på varmvattenberedaren noggrant efter att den gamla säkerhetsventilen skruvats bort. Lätt uppvärming underlättar demonteringen.

Använd gängtätning/gänglåsning av typ Loctite 577, Bondline T777, Permabond A1044 eller motsvarande vid monteringen av nya säkerhetsventilen. Dra inte fast ventilen för hårt när gängan bottnar, det kan spräcka ventilhuset.

Använd inte gängtape, det kan orsaka sprickor i ventilhuset om för mycket tape läggs på.

Safety valve SFD00005AA

The 6.0 bar/87 psi safety/relief valve SFD00005AA is mounted on Isotemp Basic, Slim A, Slim/B and Slim Square until late 2006 production.

When replacing the safety valve, clean carefully the thread on the water heater, cold water inlet, after the old valve has been taken off.

Lock and seal the thread with Loctite 577, Bondline T777, Permabond A1044 or similar when mounting the new safety valve. Do not tighten the valve too hard when the threads are bottoming, it can damage the valve housing.

Avoid usage of Teflon tape on the threads, it can expand and crack the valve housing during mounting.

2007-03-10/LLG
Publ/Safety valve 09101

Thermoprodukter AB

Dragonvägen 6
SE-392 39 Kalmar
Sweden
Tel +46 480 425 887
E-mail: info@isotherm.se
www.isotherm.se



Indel Webasto Marine S.r.l.
Zona Artigianale sn
IT-61019 S. Agata Feltria (PU) - Italy
Tel: +39 0541 848030
E-mail: info@indelwebastomarine.com
www.indelwebastomarine.com