
PACKING .IST				
Name	Quantity	Notes		
Host machine	1			
Power cable	1			
Adapter	1			
Softboard	1			
Carrying case	1			
Instructions	1			
16				





# GVM-50RS


CONTEN	ΤS		
Product introduction	Page 1		
Product parameter	Page 2		
Product structure analysis	Page 3		
Installation method	Page 4~6		
Installation of folding and external mulberry plate			
	Page 7~8		
Description of product control keys	Page 9		
Function introduction and instruction for use Page 10~11			
APP control and APP on-line control	- Page 12~13		
Precautions	Page 13		
Simple faults and troubleshooting	Page 14		
Disclaimers	Page 15		
Use and preservation	Page 15		
Packing list	Page 16		


hotography enthusiasts. The product is suitable for live / outdoor / stu otography, and also for youtube video shooting. The main feature

- ange 3200K ~ 5600k, with 384 LED bulbs, which is helpful to restore a nrich the color of objects and provide you with natural and vivid shooting
- and effectively control the light Line. You can also install folding ternal soft light board to avoid redundant light and make the light


e that once using our product correctly, you can make huc when shooting. Before using the product, you are strongly recommended to read the instructions below carefully.

# : photography fill lig' mber: GVM-50RS Color-rendering Index : ≥97 Voltage: AC:100-240V Battery Capacity: 7.4V-4400mAh\*2 ( Weight: 1.87KG Size (mm): 310x320x55 Heat Dissipation : natural way r Temperature adjusting : stepless adjustm 🔷 Origin : Huizhou, China







clockwise, and unloaded by rotating in the counterclockwise di




om the top of the light pa










### re are two power supply modes to choose. rect the power cord and adapter for power supply ase two other suitable lithium batteries and use supply. ( both battery cells must be plugged in to power )











screw hole, and lock the di





C15V power input interface

mode; WIFI username and password reset button

Color Temperature Range (3200K~5600K)

LCD screen: display brightness, hue, saturation, color temperat mode, channel value and other data

## NSTRUCTION FOR US

emperature and channel value, and it is also able to connect APP, ontrol the parameters through APP. While in the slave mode, it is o able to set channel value, rather than lightness and color temperatur

erature adjustment knob or APP, and the range is RGB.

*turned on*). The mobile phone opens the "GVM Easily" app soft of the app interface - switch device - - Select the device type as "single ar Settings - select "switch WiFi". In the WiFi list, select connect RGB Lantern WiFi (WiFi initial user name: GVM - LED, password: GVM - admin ), after the mobile when the APP main interface displays "RGB LED light ( succe *connected* )", you can control the brightness,Hue,saturation, c mperature, channel, on / off and other control keys on the APP to coness, ,Hue,saturation, color temperature, channel value and



rn to the initial (WIFI username: GVM LED, WIFI password: gvm\_admin

- different output voltage parameters.
- roduct is not waterproof, please use it in rainproof environm
- he product is not anti-corrosion, therefore do not let the product to y corrosive liquid.
- /hen using the product, make sure the product is put firmly and preve from falling and damage.
- to reduce energy loss.

Phenomenon	Check the product	Troubleshooting	
the switch indicator does not light up	① check the matching power adapter indicator light up or not.	make sure the adapter is well contacted with the power plug	
	② when using lithium battery, make sure there's no "low power" protection.	charge the battery before using it	
the knob of lightness and color temperature are out of control	check if the mode were set as slave mode, lightness and color temperature of the products cannot be controlled in slave mode	press the "mode" button for once, switch the mode from slave mode to host mode	
the screen and the light are off when the product is in the state of power-on	check if the product is "switch off" because of the APP of mobile phone.	press the "ON/OFF" button once again	

- Before using this product, please read the instructions carefully and make sur use the product correctly. If you don't obey the instructions and warnings, yo aybe cause harm to yourself and the people around, or even damage the product and other things around.
- take responsibility of any consequences of using the product.