



Carefully unscrew the upper part of the measuring magnifier.





Unscrew the threaded ring that attaches the scale to the magnifier.



Now you can carefully lever the button cells up out of their retainers using a small flat object.



Now carefully slide the new batteries downwards into the retaining brackets. Reassemble all the parts and the battery change is finished.