

## Mounting freezer compartment door

The freezer compartment door for O-evaporators has a shock cord which will hold the door in position. See picture 1 to the right.

The shock cord shall in most cases be placed on the lower part of the door, it is most often more practical to open the door from above downwards.



Place the shock cord ends behind the bottom plate of the evaporator, and tie the ends. Tighten it enough to keep the door closed with some power. See picture 2 to the left.

Check from the front side that the door sits nicely and not too firm. See picture 3 to the right and picture 4 below.



## Montering frysackslucka

Frysacksluckan för O-förångare är försedd med en gummicord, som håller den i läge på förångaren. Se bild 1 till höger.

Gummicorden ska i de allra flesta fall sitta i underkant av luckan, det är oftast mest praktiskt att luckan öppnas nedåt.



Trä in gummicorden bakom förångarens bottenplåt och knyt ihop så att den är lite spänd. Se bild 2 till vänster.

Känn efter att den sitter "lagom hårt", justera om det behövs. Se bild 3 till höger och bild 4 nedan.

