



# EQUINE FUSION®

Happy, Performing Horses!

## *All Terrain Slim*

The most comfortable hoof shoe on the market



### The key features for the flexible and elastic Jogging shoe

- 1) Safeguards the horse's natural **balance** (utilize entire area)
- 2) Safeguards the horse's natural **stability** (utilize entire area)
- 3) Ensures the horse's need for **cushioning** (natural hoof movement, absorb shock & vibrations)
- 4) Promotes a more **consistent surface contact** (adapt to the hoof-ground interface, customized grip)
- 5) Promotes a more **natural rollover motion** (natural hoof movement, customized grip)



# All Terrain Slim

Congratulations on your purchase of All Terrain Slim.

The new All Terrain slim has the same great features as All Terrain, only now it is also available to achieve a better fit for narrow hooves.

Size	Size Range Length	Size Range Width	Break over - Point	Weight
7	6.6-7.5 cm (2 5/8 - 2 15/16")	up to 6.35 cm (2 1/5")	7 mm	132 gr
8	7.6-8.5 cm (3 - 3 3/8")	up to 7.35 cm (2 7/8")	7 mm	152 gr
9	8.6-9.5 cm (3 3/8 - 3 3/4")	up to 8.35 cm (3 5/16")	7 mm	176 gr
10	9.6-10.5 cm (3 3/4 - 4 1/8")	up to 9.35 cm (3 11/16")	10 mm	231 gr
11	10.6-11.5 cm (4 3/16 - 4 1/2")	up to 10.35 cm (4 1/8")	10 mm	268 gr
12	11.6-12.5 cm (4 9/16 - 4 15/16")	up to 11.35 cm (4 1/2")	10 mm	310 gr
13	12.6-13.5 cm (4 15/16 - 5 5/16")	up to 12.35 cm (4 7/8")	10 mm	348 gr
14	13.6-14.5 cm (5 3/8 - 5 11/16")	up to 13.35 cm (5 1/4")	10 mm	439 gr
15	14.6-15.5 cm (5 3/4 - 6 1/8")	up to 14.35 cm (5 11/16")	10 mm	486 gr
16	15.6-16.5cm (6 1/8 - 6 1/2")	up to 15.35cm (6 1/16")	10 mm	533 gr

Dampening Factor	Terrain
Sole	Medium +
Sole with pad	Soft

# *All Terrain Slim*

## QUICK STEP- installation



1. Open the shoe wide



2. Place the shoe on the hoof. Make sure that the toe is all the way in front of the shoe, and that the shoe is centered in the back.



3. Put the Velcro together. Check that both Velcro's are aligned on top of each other.



4. Pull the strap firmly with a hoof pick and secure. This will pull the shoe more tightly around the hoof.



5. Lift the front flap to closed position. And secure with the Velcro on the sides.



6. Ready to run!