



























 NON-OBLIGATORY EXAMPLES FOR USE OF BESTGRIP STUDS	1000	1100	1200	1300	1350	1400	1410	1500	1600	1610	1700	1700S	1740	1750	1800	1800R	1800S	1900	1910	1911-3	1912-3	3000A	3000B	1605	3300	F1		
																												
INTERLOCKING KEY ADAPTER 1/4" Hexagonal drive use screw/handle for installation and removal	4000	4100	4200	4300	4400	4400	4400	4500	4600	4610	4700	4700S	4740	4700	4800	4800	4700S	4500	4910	4911-3	4912-3	3200	3200	3200	3500	4300		
MANUAL HANDLE 1/4" Hexagonal drive	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000	5000		
DIMENSIONS Diameter x length (mm)	6x8.4	7.9x9.8	9x12.6	9x15.2	9x14.4	9x16.2	10x16.0	9x17.5	7.7x15.3	6x21.8	9x20.8	9x23	7.7x17.4	7.7x20.9	9x23.3	9x25.5	9x21.5	9x20.5	10x19	11x22.8	12x24.5	7.9x15.1	7.9x11.4	6.7x16.6	8.6x13.2	9x14.4		
PROMINENCE (mm)	2.2	1.9	1.9	3.2	2.4	2.8	2.8	4	3.6	3.8	7.3	9	5.4	6.9	6.8	8	7.5	4	4.5	5.3	6.0	4.4	3.5	3.6	1.0	4.6		
STUD PENETRATION INTO THE RUBBER (mm)	6.2	7.9	10.7	12	12	13.5	13.2	13.5	11.7	18	13.5	14	12	14	16.5	17.5	14	16.5	14.5	17.5	18.5	10.7	7.9	13.0	12.2	9.8		
MINIMUM THREAD Misura generica (mm)	5	5.9	8.5	9.5	9.5	11	9.7	11	9.2	18	11	11.5	9.5	11.5	14	15	11.5	14	11.5	14.5	15.5					6.0		
TIP SIZE (Ø mm)	1.7 TUNGSTEN	2.2 TUNGSTEN	2.6 TUNGSTEN	2.6 TUNGSTEN	2.6 TUNGSTEN	2.6 TUNGSTEN	2.6 TUNGSTEN	2.6 TUNGSTEN	2.2 TUNGSTEN	2.2 TUNGSTEN	2.2 TUNGSTEN	1.6 TUNGSTEN	2.2 TUNGSTEN	2.2 TUNGSTEN	2.6 TUNGSTEN	2.6 TUNGSTEN	1.6 TUNGSTEN	2.6 TUNGSTEN	3.0 TUNGSTEN	3.5 TUNGSTEN	3.5 TUNGSTEN	1.7 TUNGSTEN	1.7 TUNGSTEN	1.7 TUNGSTEN	2.6 TUNGSTEN	1.7 TUNGSTEN		
ROAD CAR SNOW TIRE	B-C H=3 I=40	B-C H=5 I=40	A-B-C H=7.5 I=40		A-B-C H=9 I=40																							
4X4 OFF ROAD SNOW TIRE OFF ROAD TIRE		B-C H=5 I=40	A-B-C H=7.5 I=40	A-B H=9 I=60	A-B-C H=9 I=40	A-B-C H=10.5 I=40		A-B H=10.5 I=40							A H=13.5 I=70													
SAFETY SCHOOL DRIVE SNOW TIRE OFF ROAD TIRE			H=7.5 I=70	H=9 D-E I=70	H=9 F-G I=70		H=9.7 I=100	H=10.5 I=70																				
ON ROAD MOTORCYCLE ROAD TIRE OFF ROAD TIRE	B-C H=3 I=40	B-C H=5 I=40	A-B-C H=7.5 I=40	A-B-C H=9 I=40	A-B-C H=9 I=40	A-B-C H=10.5 I=40		A H=10.5 I=40	A-B-C H=8.5 I=40 D																			
MOTORCYCLE ENDURO CROSS RACING											A H=10.5 D I=200				A H=11 D I=200													
MOTORCYCLE ENDURO CROSS TRAINING / OFF ROAD						B-C H=10.5 G I=60		A-B-C H=10.5 G I=60	A-B-C H=8.5 D I=60		A H=10.5 D I=100		A-B-C H=9 D I=60	A H=11 D I=100	A H=13.5 G I=100													
MOTORCYCLE RACING 100% ICE												100%ICE H=11 D					100%ICE H=11 G											
SPECIAL EVENTS OFF ROAD TIRE								A-B H=10.5 I=150				A H=10.5 I=150			A H=11 D I=150	A H=13.5 G I=150	A H=14.5 G I=150											
QUAD			B-C H=7.5 D I=40	A-B-C H=9 I=40	B-C H=9 I=40	A-B-C H=10.5 I=40		A-B H=10.5 I=40								A H=13.5 I=40												
MOUNTAIN BIKE	A-B-C H=5 I=30																											
RALLY CAR ICE RACING TIRE						A-B-C H=10.5 I=100		A-B H=10.5 I=100							A H=12 I=100													
RALLY CAR RALLY ROAD TIRE SNOW TIRE		B-C H=5 I=40	A-B-C H=7.5 I=40	A-B H=9 I=40	A-B-C H=9 I=40	A-B-C H=10.5 I=40																						
RACE CARS F1 HARD RUBBER COMPOUND USE MULTI-SEAL LIQUID																										A H=6 I=400		
TRACTORS OPERATIVE CARS															A H=11 I=150 M=45					A-B-C H=9 I=150 M=60	A-B-C H=12 I=150 M=130	A-B-C H=13 I=150 M=200						
TRUCKS OPERATIVE CARS			C-B H=6.5 I=120 M=35	A-B-C H=8 I=120 M=35	B-C H=8 I=120 M=35			ICE H=10 I=120 M=35													A-B-C H=9 I=120 M=60	A-B-C H=12 I=120 M=130	A-B-C H=13 I=120 M=200					
TRACKS FOR WORK															A H=16.5 I=100						B-C H=14.5 I=100	B-C H=17.5 I=100						
TRACKS FOR SNOWMOBILES AND QUAD										H=18 I=100 L=7																		
GO-KART OFF ROAD TIRE			H=8.7 I=66	H=10 I=66	H=10 I=66	H=11.5 I=66		H=11.5 I=66																		H=7.8 I=66		
NON-SLIP SHOES FOR HORSE			B-C H=11 I=8												A H=14.5 I=8													
ANTI-WEAR SHOES SUPERMOTARD BOOTS																										H=9 I=7		
NON-SLIP SHOES FOR SPORT, RECREATION, WORK, SPORT FISHING	C-B H=6 I=10 FOOTWEAR RUBBER	C H=8 I=10 FOOTWEAR RUBBER	COMPLETE PACK art. 3000 = 20 studs (8 art. 3000A for heel + 12 art.3000B for front sole) + 1 key art. 3200 + art. 5000 art. 3010 = 20 studs 3000A + 1 key art. 3200 + art. 5000 art. 3020 = 20 studs 3000B + 1 key art. 3200 + art. 5000 art. 3030 = 20 studs 1100 + 1 key art. 4100 + art. 5000 art. 3040 = 20 studs 1000 + 1 key art. 4000 + art. 5000 art. 3050 = 20 studs 1605 + 1 key art. 3200 + art. 5000										REFILL PACK art. 3100 = 20 studs (8 art. 3000A for heel + 12 art.3000B for front sole) art. 3110 = 20 studs 3000A art. 3120 = 20 studs 3000B art. 3130 = 20 studs 1100 art. 3140 = 20 studs 1000 art. 3150 = 20 studs 1605													A-B-C H=10.7 I=10 FOOTWEAR RUBBER	A-B-C H=7.9 I=10 FOOTWEAR RUBBER	A-B-C I=10 FOOTWEAR FELT

DISTRIBUTOR

A = MUCH SNOW B = LITTLE SNOW C = WITHOUT SNOW D = FRONT TIRE WITHOUT DRIVE E = REAR TIRE WITHOUT DRIVE F = FRONT TIRE WITH DRIVE G = REAR TIRE WITH DRIVE
H = MINIMUM TREAD I = MINIMUM QUANTITY IN EVERY WHEEL OR FOOTWEAR L = WIDTH LEAST WEDGE TRACK M = TOTAL WEIGHT IN QUINTALS All measures are expressed in millimeters

VERY EFFICIENT NAILING	EFFICIENT NAILING	NOT VERY EFFICIENT NAILING
------------------------	-------------------	----------------------------

ATTENTION! For use the studs, always follow the normative in force in your own country. Bestgrip dissolves from all liability to misuse the products