

BGS 74585

Flywheel Locking Tool for Mercedes-Benz Engine M133 / M270 / M607 / M651



ATTENTION

Read the operating instructions and all safety instructions contained therein carefully before using the product. Use the product correctly, with care and only according to the intended purpose. Non-compliance of the safety instructions may lead to damage, personal injury and to termination of the warranty. Keep these instructions in a safe and dry location for future reference. Enclose the operating instructions when handing over the product to third parties.

INTENDED USE

This tool is used to lock the flywheel when loosening and tightening the central screw on the crankshaft pulley. The tool is mounted instead of the starter and engages in the flywheel teeth and is suitable for e.g. Mercedes-Benz engines: 1.5 I diesel (M607), 1.6 I petrol (M270), 2.0 I petrol (M133 & M270), installed in e.g. Mercedes-Benz A-Class (2013-2019), B-Class (2012-2019), CLA (2013-2019), GLA (2014-2020).

The tool should be used as Mercedes-Benz OEM 270 589 00 40 00.

SAFETY INFORMATIONS

- Keep children and other persons away from the working area.
- Do not allow children to play with this tool or its packaging.
- Do not use the tool if parts are missing or damaged.
- Use the tool for the intended purpose only.
- Never place the tool on the vehicle battery. There is a risk of a short circuit.
- Be careful when working on running engines. Loose clothing, tools and other objects can be caught by rotating parts and cause serious injury.
- Be careful when working on hot engines because of the risk of burn injuries!.
- If you remove the ignition key before repairing, you can prevent the engine from being started accidentally and resulting in engine damage and personal injuries.
- This manual serves as a brief guide and does not replace a workshop manual. Always refer to the vehicle-specific service literature, particularly the technical data such as torque values and instructions for disassembly/assembly, etc.

ENVIRONMENTAL PROTECTION

Recycle unwanted materials instead of disposing of them as waste. Packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. Contact your local solid waste authority for recycling information.

Tel.: 02196 720480

Fax.: 02196 7204820

mail@bgs-technic.de





USE	
Remove starter cable.	Insert tool.
Loosen the starter screws.	Make sure that the teeth on the tool engage in
Remove the starter screws.	the teeth on the flywheel.
Remove the starter.	Fix the tool with the original screws.
	W MANAGER AND
_	

Tel.: 02196 720480