



# Assembly Instructions

Parts and Tools list


NO.	Name	Qty	NO.	Name	Qty
1	Lifting System	1	11	5mm Hex Spanner	1
2	Foot Pad	4	12	Rubber Cushion	10
3	Foot Margin	2	13	ST4.8*19 Screw	12
4	M8*16 Screw	8	14	ST3.5*19 Screw	2
5	Bracket	2	15	M6*12 Screw	8
6	M6*14 Screw	8	16	M6*16 Screw	4
7	Hand Controller	1			
8	M6*10 Screw	8			
9	Support Beam	1			
10	4mm Hex Spanner	1			




- 1** Loosen the 4 screws of beam using 4MM hex spanner, adjust the beam to proper position to fit the desktop




- 2** Attach legs to the beam using 8 of M6\*14 screws and 4 of M6\*12 screws




- 3** Attach feet to the legs using 8 of M8\*16 screws, attach the 4 of levelling foot pads to the feet by hand.



- 4** Overturn frame and attach brackets to beam using 4 of M6\*12 screws, and fit the rubber cushions to the brackets and beams



- 5** Attach the control box to the underside of the desktop using 12 of ST4.8 self-tapping screws, attach handset to the underside of desktop using 2 of ST3.5 self-tapping screws. (you can use the self tapping screw or in case of inserts use the M6\*16 screw)



- 6** Connect the control box to the handset and to the motor

