

Revised 5-9-11

TOOLS NEEDED: 5MM ALLEN WRENCH 5/32" DRILL BIT AND DRILL
DUCT TAPE RUBBING ALCOHOL

INSTALLATION

NOTE: CHECK LIGHTS TO MAKE SURE THEY ALL LIGHT UP BEFORE INSTALLING ON BIKE.

1. USING 5MM ALLEN WRENCH REMOVE THE TWO BOLTS ON EACH SIDE OF THE FRONT HALF OF THE FRONT FENDER.
2. USING 5MM ALLEN WRENCH REMOVE THE TWO BOLTS HOLDING THE FRONT FORK TUBE COVER.
3. CLEAN THE INSIDE OF FRONT FENDER WELL WITH WARM SOAPY WATER.
4. CLEAN THE OUTSIDE SURFACE OF FRONT FENDER, WHERE THE ACCENT WILL BE PLACED, WITH RUBBING ALCOHOL.
5. CHECK WHERE THE ACCENT WILL BE MOUNTED ON THE FRONT FENDER AND MARK THE SPOT FOR THE WIRES TO GO THROUGH THE FRONT FENDER.
6. DRILL A 5/32" HOLE WHERE THE MARK FOR THE WIRES IS.
7. REMOVE THE PROTECTIVE BACKING FROM TAPE AND FEED THE WIRES THROUGH HOLE AND APPLY ACCENT TO FRONT FENDER, HOLD FIRMLY FOR ABOUT 30 SECONDS. DO THE SAME FOR THE OTHER SIDE.
8. RUN THE WIRES TO THE BACK PORTION OF FRONT FENDER AND SECURE TO THE INSIDE OF FENDER WITH DUCT TAPE, SO THEY DON'T RUB ON TIRE, RUN THE WIRES UP THE FORKS INTO THE TOP SHELTER AND SECURE TO THE BRAKE LINES.
9. WIRE TO RUNNING LIGHT WIRES OR TO A SWITCH.
10. CHECK TO MAKE SURE LIGHTS WORK PROPERLY BEFORE REINSTALLING ALL REMOVED PARTS.