# **Energy Management Energy Meter Type EM340**



- · Digital input (for tariff management)
- Easy connection or wrong current direction detection • Certified according to MID Directive (option PF only): see "how to order" below
- Other versions available (not certified, option X): see "how to order" on the next page

- Three phase energy meter
- Class 1 (kWh) according to EN62053-21
- Class B (kWh) according to EN50470-3
- Accuracy ±0.5% RDG (current/voltage)
- Direct current measurement up to 65AAC
- Backlit LCD display (3x 8-digit) with integrated touch key-pad
- Energy readout on display: 8 digit
- · Variable readout on display: 4 digit
- Energy measurement: kWh and kvarh (imported/ exported); kWh+ by 2 tariffs; kWh per phase
- System variables: kW, kvar, kVA, VLL, VLN, PF, Hz, kWdmd, kWdmd peak
- Phase variables: kW, kvar, kVA, VLL, VLN, A, PF
- · Self power supply
- Dimensions: 3-DIN module
- Protection degree (front): IP51
- Pulse output (optional, by open collector NPN)
- RS485 Modbus port (optional)
- M-bus port (optional)

Three-phase energy meter with backlit LCD display with integrated touch keypad. Particularly indicated for active energy metering and for cost allocation in applications up to 65 A (direct connection), with dual tariff management availability. It can measure imported and exported energy or be programmed to consider only

the imported one. Housing for DIN-rail mounting, with IP51 front degree protection. The meter is optionally provided with pulse output proportional to the active energy being measured, RS485 Modbus port or M-bus port. Available for legal metrology (PF option, only for imported energy).

**CARLO GAVAZZI** 

Certified according to MID Directive, Module B MID and Module D of Annex II, for legal metrology relevant to active electrical energy meters (see Annex V, MI003, of MID). Can be used for fiscal (legal) metrology.

How to order EM340 DIN AV2 3 X O1 PF B

Model	
Range code	
System	
Power supply	
Output	
Option	
Measurement ——	

#### **Type Selection**

Range code		Syst	tem	Power supply		Output	
AV2:	208 to 400 VLL AC - 5(65)A (Direct connection)	3:	3-phase, 3 or 4 wire; 2-phase 3 wire	<b>X</b> :	Self power supply -20% +20% of the rated measuring input voltage, 45 to 65Hz	O1: S1: M1:	pulse output RS485 Modbus port M-bus port
Optic	on			Mea	surement		
<b>PF:</b> Certified according to MID Directive. Can be used for fiscal (legal) metrology.			<b>A</b> :	The power is always in positive imported and r the total energy meter	negative	e exported power) and	
				В:	Only the total positive e according to MID.	energy	meter is certified

Product description



#### How to order EM340-DIN AV2 3 X O1 X STANDARD Model Т Range code -Not certified according to MID Directive. Cannot be used System for fiscal (legal) metrology. Power supply -Output -**Option**

# **Type Selection**

Range code		System		Power supply		Output	
AV2:	208 to 400 VLL AC - 5(65)A (Direct connection)	3:	3-phase, 3- or 4-wire; 2-phase 3-wire	X:	self power supply -20% +20% of the rated measuring input voltage, 45 to 65Hz	O1: S1: M1:	pulse output RS485 Modbus port M-bus port

#### Option

**X**: none

# Input specifications

Poted Innuite			
Rated Inputs Current type	3-phase loads, direct	Energy additional errors Influence quantities	According to EN62053-21
Current type	connection	· · · · · · · · · · · · · · · · · · ·	
Current range	5(65)A	Temperature drift	≤200ppm/°C
Nominal voltage	208 to 400 VLL AC	Sampling rate	4096 samples/s @ 50Hz 4096 samples/s @ 60Hz
Accuracy			4090 samples/s @ 00Hz
(@25°C ±5°C, R.H. ≤60%,		Display and touch key-pad	
45 to 65 Hz)	Imin=0.25A; lb: 5A, Imax:	Туре	Backlit LCD, 3 rows by
	65A; Un: 113 to 265VLN	Read-out	8-digit each, h 7 mm
	(196 to 460VLL)	Read-out	Energy: 8 digit. Variables: 4
	Imin=0.25A; Ib: 5A, Imax:	Touch key	digit 3 (DOWN, Enter and UP).
	65A; from 208 to 400 VLL AC	Max. and Min. indication	5 (DOWN, Effet and OF).
Current	From 0.04lb to 0.2lb:	Energies	Max. 99 999 999
	±(0.5%RDG+1DGT)	Energies	Min. 0.01
	From 0.2lb to Imax:	Variables	Max. 9999
	±(0.5%RDG)		Min. 0.01
Phase-neutral voltage	In the range Un: $\pm(0.5\% \text{ RDG})$	Memory	
Phase-phase voltage	In the range Un: ±(1% RDG)	Energy	10^12 cycles. Energy value
Frequency Active power	Range: 45 to 65Hz. From 0.05 In to Imax,		is saved every time the less
Active power	within Un range, PF=1:		significant digit increases.
	±(1% RDG)	Programming parameters	10^12 cycles. When a
	From 0.1 In to Imax, within		parameter is modified, only
	Un range, PF=0.5L or 0.8C:		the relevant memory cell is
	±(1% RDG)		overwritten
Power factor	±[0.001+1%(1.000 - "PF RDG")]	LEDs	Flashing red light pulses
Reactive power	From 0.05 In to Imax,		according to EN50470-3,
·	within Un range, sinphì=1:		EN62052-11, 1000 imp./
	±(2% RDG)		kWh (min. period: 90ms)
	From 0.1 In to Imax, within		Fix orange light: wrong
	Un range, sinphì=0.5L or		current direction (only with PFB option or with "B"
	0.8C: ±(2% RDG)		measurement selection in
Energies			case of X option)
Active energy	Class 1 according to	Current overloads	
	EN62053-21 Class B	Continuous	65A, @ 50Hz
	(Class B (kWh) according	For 10ms	1950 A
	to EN50470-3)	Short circuit withstand	4.5kA 10 ms according to
Reactive energy	Class 2 according to	Short should withstand	IEC62052-31:2015
Start-up current:	EN62053-23 20mA	Voltage Overloads	12002002 01.2010
Start-up current.	Self-consumption is not	Continuous	1.2 Un
	measured.	For 500ms	2 Un
Start-up voltage	90VLN	Input impedance	
Resolution	Display	230VL-N	1.2Mohm
Current	0.1 A	120VL-N	1.2Mohm
Voltage	0.1 V	5(65) A	< 1.5 VA per channel
Power	0.01 kW or kVar	Wrong connection detection	Installation guide to
Frequency	0.1 Hz	-	indicate if connections are
PF	0.01		correctly carried out. Can
Energies (positive)	0.01 kWh or kvarh		be disabled.
Energies (negative)	0.01 kWh or kvarh	Phase sequence	Indicates if the phase
	Serial communication		sequence is not the correct
Current	0.001 A	<b>.</b>	one (L1-L2-L3)
Voltage	0.1 V	Correct current direction	Indicates if the current
Power	0.1 W or var		direction is not the right one
Frequency	0.1Hz		(only with PFB option or
PF Energies (positive)	0.001		with type "B" measurement
Energies (positive) Energies (negative)	0.001 kWh or kvarh 0.001 kWh or kvarh		selection in case of X

Load conditions

Energy metering



#### Input specifications (cont.)

option). The wrong connection detection works in case of loads with: - PF>0.766 (<40°) power factor if inductive or PF>0.996 (<5°) if capacitive - a current at least equal to 10% rated current (primary current transformer) in every measuring	are summed to increase the total postive energy totalizer (kWh+), while the others increase the total negative totalizer (kWh-). Ex. P L1= +2kW, P L2 . +2kW, P L3 = -3 kW Integration time = 1 hour +kWh = $(2+2) \times 1h = 4 \text{ kWh}$ -kWh = 3 x 1h= 3kWh
(1)	

#### **Digital input specifications**

Digital inputs Function	Free of voltage contact Tariff management (switch between t1-t2)	Overload	In case a voltage is erroneously applied to the digital input, the input is not
Number of inputs	1		damaged up to 30 VAC/
Contact measurement voltage			DC.
Input impedance	1kohm		
Contact resistance	≤1kohm, close contact		
	≥100kohm, open contact		

#### **Output specifications**

RS485 serial port	RS485 by screw	Protocol	M-bus according to
-	connection.		EN13757-1
Function	For communication	Baud rate	0.3, 2.4, 9.6 kbaud
	of measured data,	Meters in the M-bus network	250
	programming parameters	Primary address	Selectable
Protocol	ModBus RTU (slave	Secondary address	Univocally defined in each
	function)		unit
Baud rate	9.6, 19.2, 38.4, 57.6, 115.2 kbaud,	Identification number range	from 9000 0000 to 9999 9999
Data format	even or no parity,	Other	Available functions: wild
Address	1 to 247 (default: 01)		card, header, initialisation
Driver input capability	1/8 unit load. Maximum 247		SND_NKE, and req_udr
	devices on the		management. Management
	same bus.		of primary address
Data refresh time	1sec		modification via M-bus and
Read command	50 words available in 1		reset of partial energy via
	read command		M-bus available.
Rx/Tx indication	Rx segment on display		VIF, VIFE, DIF and DIFE:
	is shown when a valid		see protocoll
	Modbus command is sent	Static output	
	to that specific meter	Purpose	For pulse output
	Tx segment on display		proportional to the active
	is shown when a valid		energy (kWh)
	Modbus reply is sent back	Pulse rate	Selectable in multiple of
	to the master		100
M-bus port	M-bus by screw		Max 500 or 1500 kWh
	connection.		according to pulse ON
Function	For communication of		duration
	measured data		

#### **Output specifications (cont.)**

Pulse ON duration

Output type

Selectable: 30ms or 100 ms according to EN62052-31 Open collector NPN

Load

 $\rm V_{_{ON}}$  1 VDC max. 100mA  $\rm V_{_{OFF}}$  80 VDC max.

#### **General specifications**

Operating temperature	From –25 to +70°C/from	Standard compliance	
	-13 to +158°F (PF option)	Safety	EN62052-11
	From –25 to +65°C/from	Metrology	EN62053-21, EN50470-3
	-13 to +149°F (X option),	Approvals	CE, MID (PF option only)
	indoor, (R.H. from 0 to 90%	Connections	
	non-condensing @ 40°C)	Cable cross-section area	Measuring inputs: max.
Storage temperature	From –30 to +80°C/from		16 mm <sup>2</sup> , min. 2.5 mm <sup>2</sup>
	–22 to +176°F (R.H. < 90%		with/without metallic
	non-condensing @ 40°C)		cable ferrule; Max. screw
Overvoltage category	Cat. III		tightening torque: 2.8 Nm
Utilisation category	UC2	Other terminals	1.5 mm <sup>2</sup> , Min./Max. screws tightening torque: 0.4 Nm
Insulation (for 1 minute)	4000 VAC RMS between	<del></del> .	
(	measuring inputs and		54 ··· 00 ··· 00 ····
	digital/serial output (see	Dimensions (WxHxD) Material	54 x 90 x 63 mm
	table) 4000 VAC RMS	Material	Noryl, self-extinguishing: UL 94 V-0
Dielectric strength	4000 VAC RMS for 1	Sealing covers	Included
	minute	Mounting	DIN-rail
EMC	According to EN62052-11	Protection degree	Dirvitaii
Electrostatic discharges	15kV air discharge;	Front	IP51
Immunity to irradiated	<b>3</b> ,	Screw terminals	IP20
electromagnetic fields	Test with current: 10V/m		
-	from 80 to 2000MHz;	Weight	Approx. 240 g (packing included)
Electromagnetic fields	Test without any current:		included)
	30V/m from 80 to		
	2000MHz;		
Burst	On current and voltage		
	measuring inputs circuit:		
	4kV		
Immunity to conducted			
disturbances	10V/m from 150KHz to		
Surgo	80MHz On current and voltage		
Surge	measuring inputs circuit:		
	4kV:		
Radio frequency	According to CISPR 22		



### Power supply specifications

Self power supply

208 to 400VAC VLL, -20% +20% 50/60Hz


Power consumption

≤ 1W, ≤ 10VA


#### Insulation (for 1 minute) between inputs and outputs

	Measuring input	Digital or serial output	Digital input
Measuring input	-	4 kV	4 kV
Digital or serial output	4 kV	-	0 kV
Digital input	4 kV	0 kV	-

### Accuracy (according to EN50470-3 and EN62053-23)



kvarh, accuracy (RDG) depending on the current



# **Display pages**

No	1 <sup>st</sup> row	2 <sup>nd</sup> row	3 <sup>rd</sup> row	"Full" mode	"Easy" mode	Note
0	kWh+ (imported)		kW system	Х	Х	In PF version (MID) this is the only certified energy meter. In PFA version and in X version with Measurement menu set to "A", this is considering the total energy without considering the current direction.
1	kWh- (exported)		kW system	х	Х	Only in X version, with Measurement menu set to "B"
2	kWh+ (imported)		V L-L system	х	Х	
3	kWh+ (imported)		V L-N system	Х	Х	
4	kWh+ (imported)		PF system	Х		
5	kWh+ (imported)		Hz	Х		
6	kvarh+ (imported)		kvar system	Х	X	In X version with Measurement menu set to "A", this is considering the total positive reactive energy without considering the current direction.
7	kvarh- (exported)		kvar system	Х	Х	Only in X version, with Measurement menu set to "B"
8	kWh+ (imported)		kVA system	Х		
9	kWh+ (imported)	kWdmd peak	kWdmd	Х		
10	kWh (t1)	"t1"	kW system	Х	Х	Only relevant to kWh+, with Tariff menu set to ON.
11	kWh (t2)	"t2"	kW system	Х	Х	Only relevant to kWh+, with Tariff menu set to ON.
12	kWh L1	kWh L2	kWh L3	Х		In X version with Measurement menu set to "A", this is considering the total energy without considering the current direction. In PFB version and in X version with Measurement menu set to "B", this is considering only the imported energy.
13	kVA L1	kVA L2	kVA L3	Х		
14	kvar L1	kvar L2	kvar L3	Х		
15	PF L1	PF L2	PF L3	Х		
16	VL-NL1	VL-NL2	VL-NL3	Х		
17	V L-L L1	VL-LL2	VL-LL3	Х		
18	A L1	A L2	A L3	Х	Х	
19	kW L1	kW L2	kW L3	Х		


X= available




# Additional available information on the display


Туре	Description	Note
Info 1	Year (2016)	Year of production
Info 2	Serial (dddnnnA)	Serial number (ddd= day of the year; nnn=progressive number; A= production line, internal use only)
Info 3	Rev (A.01)	Firmware revision
Info 4	Puls led	Led pulsed/kWh
P3	System	System type
P6	Measure	Measurement type
P7	Install	Wrong connection detection
P8	P int	Integration time for Wdmd calculation
P9	Mode	Set of variables on display
P10	Tariff	Tariff enabling
P11	Home	Selected home page
P12-1	Pulse duration	Pulse ON duration
P12-2	Pulse rate	Pulse rate
P13	Primary address	M-bus primary address
P14	Address	Modbus serial address
P15	Kbaud	M-bus or Modbus baud rate
P16	Parity	Modbus parity
Info 5	Secondary address	M-bus secondary address


# Wiring diagrams





#### Wiring diagrams (cont.)

















#### Front panel description



- 1. Display Backlit LCD display with touch key-pad.
- 2. LED LED proportional to kWh reading
- 3. Serial number Area reserved to serial number and MID-relevant data in PF versions

#### Dimensions

